

REAR BRAKE DRUMS/HUBS

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
862-492 RH DRUM/HUB 862-493 LH DRUM/HUB	1 1		1935-37 all DODGE		
862-356 DRUM/HUB	2	1936-38 all PLYMOUTH			
862-315 RH DRUM/HUB 862-316 LH DRUM/HUB	1 1		1939-42 exc long w/ base		
862-356 RH DRUM/HUB 862-357 LH DRUM/HUB	1 1	1939-42 all PLYMOUTH			
862-358 RH DRUM/HUB 862-359 LH DRUM/HUB	1 1			1946-48 exc long w/ base	
862-360 RH DRUM/HUB 862-361 LH DRUM/HUB	1 1				1946-49 6-cylinder exc long w/ base
942-041 RH DRUM/HUB 942-042 LH DRUM/HUB	1 1	1946-54 all PLYMOUTH 1955-56 w/ 10" brakes			
962-047 RH DRUM/HUB 962-048 LH DRUM/HUB	1 1		1946-48 exc long w/ base 1949-52 exc WAYFARER 1953-54 6-cylinder w/ 11" brakes 8-cylinder 1955 all DODGE 1956 w/ 11" brakes		
862-325 RH DRUM/HUB	1			1949 estate wagon	
962-018 RH DRUM/HUB 926-019 LH DRUM/HUB	1 1			1952-55 estate wagon	1946-52 8-cylinder 1953-55 estate wagon & IMPER
862-380 RH DRUM/HUB 862-381 LH DRUM/HUB	1 1			1950-51 all DESOTO	
862-327 RH DRUM/HUB 862-328 LH DRUM/HUB	1 1				1950-52 WINDSOR SARATOGA 1953-55 exc IMPERIAL exc estate wagon
862-362 RH DRUM/HUB 862-363 LH DRUM/HUB	1 1			1952-55 exc estate wagon	
862-451 RH DRUM/HUB 862-452 LH DRUM/HUB	1 1	1955-56 w/ 11" brakes			
962-026 RH DRUM/HUB 962-027 LH DRUM/HUB	1 1	1957-59 w/ 11" brakes	1959 CORONET		
862-303 RH DRUM/HUB 862-304 LH DRUM/HUB	1 1			1956 exc estate wagon	
862-302 RH DRUM/HUB 862-303 LH DRUM/HUB	1 1		1956 w/ 12" brakes		1956 exc estate wagon exc IMPERIAL

REAR BRAKE DRUMS/HUBS (CONT'D)

ATLAS P/N	QTY REQ	PLYMOUTH	DODGE	DESOTO	CHRYSLER/ IMPERIAL
862-399 RH DRUM/HUB 862-400 LH DRUM/HUB	1 1			1956 estate wagon	1956 estate wagon IMPERIAL
962-014 RH DRUM/HUB 962-015 LH DRUM/HUB	1 1		1957-58 w/ 11" brakes 1959 w/ 11" brakes exc CORONET	1957-59 w/ 11" brakes	1958-59 w/ 11" brakes
962-076 RH DRUM/HUB 962-077 LH DRUM/HUB	1 1		1957-59 Coronet w/ 11" x 2" brakes		
962-039 RH DRUM/HUB 962-040 LH DRUM/HUB	1 1	1957-59 w/ 12" brakes	1957-59 w/ 12" brakes	1957-59 w/ 12" brakes	1957 exc IMPERIAL 1958-59 w/ 12" brakes exc IMPERIAL
862-388 RH DRUM/HUB 862-389 LH DRUM/HUB	1 1				1957-59 all IMPERIAL